

Mobile Hotspot network name (SSID) & password

- The Mobile Hotspot network name (SSID) is the name of the Wi-Fi network you'll need to connect to.
- The default Mobile Hotspot network name (SSID) and password can be found on the device display. Just press the Power/Menu button shortly when the display is on..
- The default SSID is "FranklinT9 + the last 4 digits of the IMEI" and the default Wi-Fi password is a random password. Please find the password on the display screen of the device.

Turn on / off

Turn on

1. Press the **Power/Menu** button on the mobile hotspot for 3 seconds. The LED indicator will light up and the display screen will turn on.
2. Wait for the **Network** and **Wi-Fi** Indicators to come on, one at a time.
3. When the Network and Wi-Fi icons light up blue, the Wi-Fi connection is enabled.

Turn off

1. Press the **Power/Menu** button on the mobile hotspot until "Goodbye" message appears on the display screen. The LED indicator light will also turn off.
2. The Network and Wi-Fi connections have been disabled.

Connect to the Mobile HotSpot

To connect your Wi-Fi enabled device to your Mobile Hotspot for internet access, follow these steps:

1. Make sure your Mobile Hotspot is turned on.
2. Select the Wi-Fi Network Name (SSID).
 1. The Wi-Fi network name and password can be found on the display screen. Just press the power/menu button shortly when the display is on.
 - The default is "FranklinT9 + the last 4 digits of IMEI".
 - The IMEI can be found on the back of the device, under the battery, or on the box it came in.
3. Enter the Wi-Fi Password. The default password is a random password and can be found on the device display screen. Just press the **Power/Menu** button shortly when the display is on.